Operating instructions
Heat pump tumble dryer



To avoid the risk of accidents or damage to the appliance, it is **essential** to read these instructions before it is installed and used for the first time.

en-AU, NZ

M.-Nr. 10 205 050

Caring for the environment


Disposal of the packing material

The packaging is designed to protect the appliance from damage during transportation. The packaging materials used are selected from materials which are environmentally friendly for disposal and should be recycled.

Recycling the packaging reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites. Ensure that any plastic wrappings, bags etc. are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation.

Disposing of your old appliance

Electrical and electronic appliances often contain materials which, if handled or disposed of incorrectly, could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your appliance. Therefore, please do not dispose of your old appliance with your household waste.



Please dispose of it at your local community waste collection / recycling centre.

Ensure that your old appliance presents no danger to children while being stored for disposal.

Energy saving tips

To avoid unnecessarily long drying times and high consumption of energy:

– Make sure that your laundry is thoroughly spun before drying. The higher the spin, the greater the savings that can be made in energy and time during drying, e.g. approx. 20% energy can be saved if spun at 1600 rpm instead of 1000 rpm.

– Load according to the optimum amount of laundry recommended for the programme being used. Underloading is uneconomical. Overloading gives a poorer quality of drying and may cause unnecessary creasing.

– Make sure the room temperature is not too high. If there are other heat producing appliances in the room in which the tumble dryer is located, make sure the room is well-ventilated and switch the other appliances off, if possible.

– Clean the fluff filters in the door opening after every drying cycle.

Contents

Caring for the environment 2

Warning and Safety instructions 6

Operating the tumble dryer 17
Control panel 17
Display 18

Before using for the first time 19

1. Notes on correct laundry care 20
Points to note regarding washed laundry 20
Preparing the laundry before drying 20
Garment care label symbols 21
Laundry care when drying in a tumble dryer 21

2. Loading the tumble dryer 22

3. Selecting a programme and starting it 23
Selecting a programme 23
Select any Extras or Delay start (if required) 25
Starting the programme 25

4. Removing the laundry at the end of the programme 26
End of programme/Anti-crease 26
Removing the laundry 26

Extras 27
Gentle tumble 27
Anti-crease 27
Buzzer 27

Delay start 28

Programme chart 29

Changing the programme sequence 32

Cleaning and care 33
Emptying the condensed water container 33
Fluff filters 34
Removing visible fluff 34
Cleaning the fluff filters and air flow openings thoroughly 35

Contents

Plinth filter ... 36
Removing the plinth filter ... 36
Cleaning the plinth filter ... 36
Cleaning the plinth filter panel ... 37
Checking the heat exchanger unit ... 37
Replacing the plinth filter ... 38

Fragrance flacon ... 40
Inserting a fragrance flacon ... 40
Replacing the fragrance flacon ... 42

Problem solving guide ... 44
Problem solving guide ... 44
Check indicators and fault messages ... 44
Unsatisfactory drying results ... 46
Other problems ... 47
Bottom right grille ... 49

After sales service ... 50
Repairs ... 50
Optional accessories ... 50
Warranty ... 50

Installation and connection ... 51
Front view ... 51
Rear view ... 52
Transporting the dryer ... 52
Installation ... 53
Levelling the dryer ... 53
Ventilation ... 53
Before moving the tumble dryer again (e.g. when moving houses) ... 54
Additional installation requirements ... 55
Externally draining condensed water ... 56
Installation conditions requiring a non-return valve ... 56
Arranging the drain hose ... 57
Examples ... 58
Electrical connection ... 60


Consumption data ... 61

Technical data ... 62

Programmable functions ... 64
Programming ... 64

Contents

Example 66
P01 Cottons programme - drier or damper 67
P02 Minimum iron programme - drier or damper 67
P04 Extended cool down 67
P05 Buzzer volume 67
P06 Keypad tones 67
P07 PIN Code 68
P08 Conductivity 68
P09 Additional drying levels 69
P11 Standby 70
P12 Automatic switch-off 71
P13 Memory 71
P14 Anti-crease 71



▶ It is essential to read these instructions.

This tumble dryer complies with current local and national safety requirements. Inappropriate use can, however, lead to personal injury and damage to property.

To avoid the risk of accidents and damage to the tumble dryer, please read these instructions carefully before using it for the first time. They contain important information on its safety, installation, use and maintenance.

Keep these instructions in a safe place and ensure that new users are familiar with the content. Pass them on to any future owner.

Correct application

▶ This tumble dryer is designed for domestic use and for use in similar environments by guests in hotel or motel rooms, bed & breakfasts and other typical living quarters. This does not include common/shared facilities or commercial facilities within hotels, motels or bed & breakfasts.

▶ This tumble dryer is not suitable for outdoor use.

▶ It must only be used to dry items which have been washed in a water solution and which are marked on the manufacturer's care label as being suitable for tumble drying. If using dry cleaning kits, do so at your own risk, and follow the instructions provided on the packaging.
Any other applications may be dangerous. Miele cannot be held liable for damage resulting from incorrect or improper use or operation.

▶ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they are supervised whilst using it or have been shown how to use it by a person responsible for their safety.

Safety with children

▶ Young children must not be allowed to use this appliance.

▶ Older children may only use the appliance when its operation has been clearly explained to them and they are able to use it safely, recognising the dangers of misuse.

▶ Children must not be allowed to clean or maintain the tumble dryer unsupervised.

▶ Please supervise children in the vicinity of the tumble dryer and do not let them play with it.

Technical safety

▶ Before setting up the tumble dryer, check it for any externally visible damage.
Do not install or use a damaged tumble dryer.

▶ Before connecting the tumble dryer, ensure that the connection data on the data plate (fuse rating, voltage and frequency) matches the mains electricity supply. If in any doubt, consult a qualified electrician.

▶ The electrical safety of this tumble dryer can only be guaranteed when correctly earthed. It is essential that this standard safety requirement is met. If in any doubt, please have the household wiring system tested by a qualified electrician. Miele cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).

▶ Reliable and safe operation of this tumble dryer can only be assured if it has been connected to the mains electricity supply.

▶ Do not connect the tumble dryer to the mains electricity supply by an extension lead. Extension leads do not guarantee the required safety of the appliance (e.g. danger of overheating).

▶ If the connection cable is faulty, it must only be replaced by a Miele approved service technician to protect the user from danger.

▶ Unauthorised repairs could result in unforeseen dangers for the user, for which Miele cannot accept liability. Repairs should only be undertaken by a Miele authorised service technician, otherwise any subsequent damage will not be covered by the warranty.

▶ Faulty components must only be replaced by genuine Miele spare parts. Miele can only guarantee the safety of the appliance when Miele replacement parts are used.

▶ In the event of a fault or for cleaning purposes, the tumble dryer is only completely isolated from the electricity supply when:

– it is switched off at the wall socket and the plug is withdrawn, or
– it is switched off at the mains circuit breaker.

▶ This tumble dryer must not be installed and operated in mobile installations (e.g. on a ship).

▶ Do not make any alterations to the tumble dryer, unless authorised to do so by Miele.

▶ Heat pump technology and refrigerant:
The heat pump in this tumble dryer uses a refrigerant which is condensed by the compressor and led in a closed circuit through the heat exchanger unit where heat exchange with the circulating drying air takes place.

– The humming noises caused by the heat pump are normal and do not impair the efficient functioning of the dryer.
– The refrigerant is not flammable or explosive.
– In general it is not necessary to leave the dryer standing for any length of time before it is connected to the mains provided it has been transported and installed correctly.

Warning and Safety instructions

▶ Please observe the instructions in "Installation and connection" and "Technical data".

▶ The accessibility of the plug must be always ensured in order to separate the tumble dryer from the mains.

▶ Do not block the gap between the bottom of the tumble dryer and the floor with plinth facings, deep pile carpet etc. This would hinder a sufficient flow of air to the tumble dryer.

▶ Make sure the dryer door can be opened without hindrance after installation.

Correct use



⚠ Caution! Risk of fire.

To avoid the possible danger of fire, please read these warnings carefully.

⚠ A clogged filter is a fire hazard!

The fluff filter must be cleaned after every programme.

▶ The maximum load for this tumble dryer is 8.0 kg (dry weight). See the "Programme chart" for the maximum recommended loads for individual programmes.

▶ To prevent the risk of fire, do not connect the tumble dryer via a controllable socket (e.g. a timer or a peak-load switch-off device). If the drying programme is interrupted before the end of the cooling down phase, this could cause the laundry to self-ignite.

▶ To prevent the risk of fire, the following textiles must not be dried in this tumble dryer:

– Items which have not been washed.
– Items, such as workwear, which have not been thoroughly cleaned and which are still soiled with grease, oil or other desposits (such as cosmetics, lotions etc). If items have not been thoroughly cleaned, there is a danger that these might ignite when heated, even after they have been removed from the dryer at the end of the programme.
– Items that have been soiled with substances such as cooking oil, acetone, petrol, kerosene, spot removers, turpentine, waxes, wax removers and other chemicals (e.g. mops and floor cloths).
– Items which have been splashed with hair lacquer, hair spray, nail varnish remover or similar substances.

When washing such heavily soiled items ensure that you use sufficient detergent and select a high temperature. If in doubt, wash the items several times.

▶ Oil-affected items can ignite spontaneously, especially when exposed to heat sources such as in a tumble dryer.
The items become warm, causing an oxidation reaction in the oil. Oxidation creates heat.
If the heat cannot escape, the items can become hot enough to catch fire. Piling, stacking or storing oil-affected items can prevent heat from escaping and so create a fire hazard.
If it is unavoidable that fabrics contaminated with vegetable or cooking oil, or hair care products, be placed in a tumble dryer, they should first be washed in hot water with extra detergent - this will reduce, but not eliminate, the hazard.

▶ Remove all items from pockets (e.g. lighters, matches).

▶ **Warning:** Ensure that you always wait until the end of the programme before removing the laundry. If the drying programme is stopped prematurely, remove the laundry immediately and hang it up or spread it out to cool it down.

▶ Fabric softener and similar products must be used according to the instructions on the manufacturer's packaging.

▶ To prevent the risk of fire, the following textiles must not be dried in this tumble dryer:

– Items which have been cleaned using chemicals (e.g. professional dry-cleaning agents).
– Fabrics which contain a large proportion of rubber, foam rubber or rubber-like materials. For example, products made from latex foam rubber, shower caps, waterproof textiles, rubberised articles and items of clothing and pillows with foam rubber filling.
– Damaged fabrics which contain padding or fillings (e.g. pillows, jackets). When damaged, the filling can get out with the risk of it igniting in the dryer.

▶ In many programmes, the heating phase is followed by a cooling down phase to ensure that the items are not too hot to handle when you remove them (this also avoids the danger of the laundry self-igniting). The programme is not finished until the cooling down phase has been completed.
As soon as the programme has finished, remove all laundry from the drum.

▶ Do not let anyone sit or lean on the door, as this can cause the tumble dryer to tip up.

▶ Always close the door after use. This way you will avoid the danger of:

– children climbing onto or into the dryer or hiding things in it.
– pets or other small animals climbing into it.

▶ The tumble dryer must not be used without or

– with damaged fluff filters.

– with a damaged plinth filter.

This would cause an excessive build-up of fluff which in turn would cause a fault.

▶ The fluff filters must be cleaned after every drying cycle.
Fluff must not be allowed to accumulate around the tumble dryer.

▶ The fluff filters and the plinth filter must be thoroughly dried after cleaning. Do no replace them if they are damp or wet. Damp or wet filters could cause operational faults.

▶ Do not install the tumble dryer in a room where there is a risk of frost occurring. At temperatures around freezing point the tumble dryer may not be able to operate properly. There is a risk of damage if the condensed water is allowed to freeze in the pump and hoses.

▶ If the water is drained externally through the drain hose instead of being collected in the condensed water container, make sure the drain hose is securely attached if you hang it in a sink or basin to avoid the hose slipping and the water causing damage.

▶ Condensed water is not drinking water.
It can cause health problems in both people and animals.

▶ Always keep the area around the tumble dryer free of dust and fluff.
Dust drawn into the tumble dryer can cause blockages in the heat exchanger over time.

▶ The tumble dryer must not be hosed down.

Using a fragrance flacon (optional accessory)

▶ Only use genuine Miele original fragrance flacons.

▶ The fragrance flacon must be stored in its packaging so please make sure you retain this.

▶ Caution. The fragrance can run out of the flacon. Make sure that you always keep the flacon, or the fluff filter with the flacon inserted in it, in a horizontal position when carrying and do not tip or place down on any surface.

▶ Use an absorbent cloth immediately to wipe up any fragrance which has run out of the flacon onto the floor, the dryer or any dryer components (e.g. the fluff filter).

▶ If fragrance which has run out of a flacon should come in contact with the **skin** - wash the skin thoroughly with soap and water; come in contact with the **eyes** - rinse the eyes with clean water for at least 15 minutes; be swallowed - rinse out the **mouth** thoroughly with clean water. Seek medical advice in the case of contact with the eyes or if fragrance has been swallowed.

▶ If fragrance which has run out of a flacon comes in contact with clothing, change the clothing immediately. Wash the clothing or any cloths used for mopping up fragrance thoroughly with plenty of water and detergent.

▶ There is the risk of fire or damage to the tumble dryer if the following instructions are not observed:

– Never refill a flacon with fragrance.

– Never use a faulty fragrance flacon.

▶ Dispose of an empty fragrance flacon with the household waste and never use it for any other purpose.

▶ Please also observe the information supplied with the fragrance flacon.


Accessories

▶ Only use genuine Miele spare parts and accessories with this appliance. If spare parts or accessories from other manufacturers are used, this will invalidate the warranty, and Miele cannot accept liability.

▶ A Miele tumble dryer can be stacked on top of a Miele washing machine using the appropriate stacking kit (available as an optional accessory). Please make sure you order the correct one for the Miele washing machine and Miele tumble dryer.

⚠ Miele cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

Control panel



① **Display with ◇ and ∨ sensors**
See the following page for more information.

② ***Start*/*Stop* button**
For starting the programme selected and cancelling a programme once it has started.


③ **Extras buttons**
Various options can be added to the programmes.

④ **Programme selector**
For selecting the programme.

⑤ **Optical interface**
For service technicians.

⑥ ⏻ **button**
The tumble dryer is switched on and off by pressing this button. To save energy, the dryer will switch off automatically 15 minutes after the end of the programme / Anti-crease phase or after being switched on if no other selection is made.

Display



⑦ **Time display**
The programme duration remaining will be displayed in hours : minutes. The duration displayed for the *Cottons, Minimum iron, Delicates, Express, Denim, Gentle smoothing* programmes may vary or "jump". The following factors, among others, affect the programme duration displayed: the quantity of the laundry, the type of fabric and the residual moisture in the laundry. The electronics continually access conditions in the appliance and then adjust the programme duration with increasing accuracy.

⑧ **Check/Fault indicators**
These are only visible when necessary.
... empty the condensed water container or check the drain hose
... clean the plinth filter/airways
... technical fault, call Miele

⑨ **Drying level display**
For selecting the drying level for programmes with a selectable drying level. See "⑫ ∨ sensor".

⑩ ◇ **sensor**
The sensor has two functions.
Touching the symbol will . . .
. . . select a later start time for the programme (Delay start). ◇ will flash during selection, ◇ will light up constantly when the Delay start time is counting down.
. . . select the duration of the *Warm air* programme. ◇ will flash during selection.

⑪ ***Perfect Dry*** **indicator**
With programmes with a selectable drying level, the Perfect Dry system calculates the residual moisture present in the laundry to ensure a precise drying result.
The *Perfect Dry* indicator . . .
. . . will flash after the programme has started and go out when the programme duration appears in the display.
. . . will light up again when the selected drying level is reached and remain on until the end of the programme.
. . . will remain dark with the following programmes: *Woollens handcare, Silks handcare, Warm air.*

⑫ ∨ **sensor**
Touching this symbol will select the drying level required which will then light up ⑨.

Removing the protective foil and stickers

■ Please remove

– the protective foil from the door.

– any stickers from the front and the lid.

⚠ Please do not remove any labels (e.g. the data plate) which are visible when you open the door.

After installing the tumble dryer

⚠ Before using the tumble dryer for the first time, ensure that it is installed and connected to the electricity supply correctly. If it has not been transported as described in "Installation and connection", then it must be left to stand for at least 1 hour before it is connected to the electricity supply.

Follow the procedure for using for the first time outlined in these instructions.

■ Read "1. Notes on correct laundry care" and "2. Loading the tumble dryer".

■ You can then load the tumble dryer and select a programme as described in "3. Selecting and starting a programme".

Points to note regarding washed laundry

– When washing very heavily soiled items, ensure that you use sufficient detergent and select a high temperature. If in doubt, wash the items several times.

– Do not put soaking wet items into the tumble dryer. Make sure your laundry is thoroughly spun before drying. The higher the spin speed, the greater the savings that can be made in energy and time during drying.

– New dark coloured garments should be washed and dried separately from light coloured garments to avoid the danger of colours running and discolouring other garments or even plastic components in the dryer. Dark coloured fibres can also settle on light coloured garments and vice versa.

– Starched laundry can be dried in the tumble dryer. To achieve the usual finish, double the amount of starch should be used.

Preparing the laundry before drying

⚠ Make sure that any objects, e.g. detergent dosing balls, lighters etc. have been removed from the laundry.

They could melt or explode and cause damage to the tumble dryer or the laundry.

⚠ See "Warning and Safety" instructions for further information.

Loading or using the tumble dryer incorrectly could cause a fire.

– Sort the laundry according to the type of fibre and weave, size, garment care label symbol and the drying level required.

– Check the seams of padded or down-filled items to prevent the risk of fillings coming out. These could catch fire when being dried.

– Disentangle the laundry.

– Tie together textile belts and apron ties.

– Fasten . . .
. . . duvet covers and pillow cases to prevent small items from being trapped inside them.
. . . hooks and eyes.

– Sew in or remove underwiring from bras.

– Leave jackets open and undo any long zips so that textiles dry evenly.

– Minimum iron fabrics tend to crease more, the greater the load. This is also the case for garments made from very fine weave fabric, such as shirts or blouses. If necessary, reduce the size of the load for these types of fabric.

Garment care label symbols

Drying	
	Normal/Higher temperature
	Reduced temperature: Select *Gentle tumble* (for delicate textiles)
	Do not tumble dry
Ironing	
	Very hot
	Hot
	Warm
	Do not iron

Laundry care when drying in a tumble dryer

See the "Programme chart".
This describes the programmes and gives their maximum load.

– Load according to the optimum amount of laundry recommended for the programme being used. Underloading is uneconomical. Overloading gives a poorer quality of drying and may cause unnecessary creasing.

– Select an appropriate drying level, e.g. . . .
. . . *Normal* if you want to fold and put away the laundry after you take it out of the dryer.
. . . *Machine iron* if the laundry, e.g. table linen, requires further processing after drying.

– Down-filled garments have linings which have a tendency to shrink, depending on the quality of the item. They can be partially dried using the *Gentle smoothing* programme.

– Pure linen should only be machine dried if specified as suitable by the manufacturer on the care label, as the surface of the fabric may otherwise become rough. It can be partially dried using the *Gentle smoothing* programme.

– Woollens and wool blends tend to become matted and shrink if dried in a tumble dryer. They can, however, be "fluffed up" in the *Woollens handcare* programme.

– Loopknit garments (e.g. T-shirts and underwear) tend to shrink depending on their quality. Do not overdry these textiles. When purchasing these garments, it is advisable to take their shrinkage properties into account.

– Select the *Gentle tumble* Extra for fabric which is particularly heat-sensitive or susceptible to creasing.

2. Loading the tumble dryer


⚠ It is essential to read "1. Notes on correct laundry care" first of all.

■ **Switch the tumble dryer on by pressing the ⏻ button.**

The interior drum lighting will come on.

The interior drum lighting will automatically go out after a few minutes and/or after the start of a programme to save energy.

Opening the door



■ Reach under the door grip and pull the door open.


■ Unfold the laundry and load loosely into the drum.

Do not overload the drum.

Overloading can cause unnecessary wear and tear to the laundry, give a disappointing drying result and cause more creasing.


When closing the door, make sure that laundry does not get trapped in the door opening.

This could damage the laundry.




If you are not using a fragrance flacon: the tab must be pushed down completely (see arrow).

Closing the door



■ Shut the door with a gentle swing.

Selecting a programme



■ Turn the programme selector.

A drying level or Extras buttons may also light up and durations will appear in the time display.

Programmes with drying levels

– ***Cottons, Minimum iron, Delicates, Express, Denim, Gentle smoothing***

The drying level can be altered after selecting one of these programmes.



■ Touch the ∨ sensor to select the drying level required.

Any drying level can be selected for the *Cottons* and *Express* programmes. A more limited range is available when using the other programmes.

Additional drying levels

Useful tip: By using the programmable functions, you can activate/deactivate additional drying levels.

If 2 drying levels are lit up	**then the following additional drying level is selected**
Extra dry *Normal*	**Normal+** = drier than *Normal*
Normal *Hand iron*	**Slightly dry** = damper than *Normal*
Hand iron *Machine iron*	**Hand iron** ∂∂ = damper than *Hand iron*

– Please see "Programmable functions - *P09* Additional drying levels".

Other programmes and the timed drying programmes

– ***Cottons*** ⬭, ***Woollens handcare, Silks handcare***

The drying level is preset and cannot be altered.

– ***Warm air***

You can select the duration in ten-minute stages.



■ Touch the ◈ sensor repeatedly until the programme duration you want appears in the time display.


– ◈ will flash

You can select the duration in ten-minute stages from *0:20* minutes up to *2:00* hours.

Select any Extras or Delay start (if required)

Please see "Extras" for further information.

Extras



■ Press any button.

The button will light up when the Extra is selected.

Delay start

You can delay the start of the programme.
However: Delay start cannot be used with the *Warm air* programme.



■ Touch the ◈ sensor.

– ◈ will flash.

Please see "Delay start" for more information.

Starting the programme

■ Press the flashing *Start*/*Stop* button.

The *Start*/*Stop* button will now light up constantly.

The *Perfect Dry* indicator will only flash/ light up with programmes with selectable drying levels (see also "Operating the tumble dryer").

The laundry will be cooled down shortly before the end of the programme.

4. Removing the laundry at the end of the programme

End of programme/Anti-crease

At the end of the programme: *0:00* will light up in the display and the *Start*/*Stop* button will go out. The anti-crease function, if selected, will then switch on for a maximum of 2 hours.


10 minutes after the end of the programme the *Start*/*Stop* button will begin to flash slowly and the display will go out: the appliance is in Standby mode to save energy.

The dryer will switch off automatically 15 minutes after the end of the anti-crease phase (with programmes without an anti-crease phase it will switch off 15 minutes after the end of the programme).

Removing the laundry

⚠ **Never** open the door before the drying process has finished.

- Reach under the door grip and pull the door open.



- Remove the laundry.


Check that all items have been removed from the drum.
If items are left in the dryer, they could be damaged by overdrying when the dryer is next used.

If the dryer is switched on at the mains and the door is opened, the drum lighting will come on. It will go out a few minutes later to save energy.

- If the dryer is still switched on, switch it off with the ⏻ button.

A buzzer will sound.

- Remove the fluff from the 2 fluff filters in the door opening (see "Cleaning and care - Fluff filters").
- Shut the door with a gentle swing.
- Empty the condensed water container.



The Extras are switched on or off by pressing the appropriate button.

The button will light up when the Extra is selected.

Gentle tumble

Delicate fabric (with the ⊡ symbol on the care label, e.g. acrylic garments) is dried at a lower temperature. The programme duration is longer.

Anti-crease

Depending on the programme selected, the drum will continue to rotate in a special rhythm for up to 2 hours at the end of the programme, to reduce creasing, if you do not wish to remove the laundry immediately.

Buzzer

A buzzer (four beeps at intervals for a maximum of 1 hour) will sound to let you know that the programme has finished. The continuous buzzer which sounds when there is a fault is not dependent on the setting for the buzzer at the end of the programme.

Selectable Extras

	Gentle tumble	Anti-crease	Buzzer
Cottons ⬡	–	X	X
Cottons	X	X	X
Minimum iron	X	X	X
Woollens handcare	–	–	X
Silks handcare	–	X	X
Delicates	O	X	X
Express	–	X	X
Denim	X	X	X
Gentle smoothing	O	X	X
Warm air	X	X	X


X = Can be selected
O = Cannot be changed/always active
– = Cannot be selected

Delay start

Selecting Delay start

With Delay start you can delay the start of the programme by up to a maximum of 24 hours.

However: Delay start cannot be used with the *Warm air* programme.



- After selecting the programme, touch the ⏲ sensor.
- – ⏲ will flash.
- – From *0:30* to *10h* Delay start is selected in half-hour increments, and from then up to *24h* in one-hour increments.
- – If you keep your finger on the sensor, the time will count up to *24h*.
- – Touching the *24h* sensor again when ⏲ is in the display will delete the time selected.

Starting Delay start

- Press the *Start*/*Stop* button.
- – ⏲ lights up.
- – Delay start times of more than *10h* will count down in hours and then in minutes until the start of the programme.
- – The drum will turn briefly every hour until the start of the programme to reduce creasing.

Changing Delay start after it has started counting down

- Press the *Start*/*Stop* button.
- – ⏲ will flash.
- Touch the ⏲ sensor to change the time.
- Press the *Start*/*Stop* button.

Adding or removing laundry before a programme starts

- You can open the door to add/ remove laundry.
- – All programme settings will be saved.
- – ⏲ will flash.

You can change the drying level, if required.

- Press the *Start*/*Stop* button so that the Delay start time continues to count down.

Cancelling Delay start

- Switch the dryer off and then on again.

Cottons	**Max. load 8.0 kg***
Items	Cotton items such as those described under *Cottons Normal* with normal residual moisture.
Note	Items are dried to a *Normal* level only.
Cottons	**Max. load 8.0 kg***
Extra dry, Normal	
Items	Single and multi-layered cotton fabric such as towelling, jerseywear, T-shirts, underwear, workwear, covers, flannelette bed linen and baby clothes.
Notes	– Select *Extra dry* for multi-layered and very thick fabrics. – Do not use *Extra dry* for jersey fabrics (e.g. T-shirts, underwear), as they have a tendency to shrink.
Hand iron, Machine iron	
Items	Cotton or linen fabric requiring further processing, e.g.: table linen, bed linen, starched laundry.
Note	To prevent laundry from drying out it should be rolled up until you are ready for ironing.
Minimum iron	**Max. load 4.0 kg**
Normal, Hand iron	
Items	Minimum iron items made of cotton, synthetic or mixed fibre, e.g.: tops, dresses, shirts, blouses, skirts, trousers and table linen.

* Weight of dry laundry

Programme chart

Woollens handcare	**Max. load 2.0 kg**
Items	Woollen garments and fabric containing wool blends, e.g. pullovers, jackets.
Notes	– Wool and wool blend items are only fluffed up; they are not dried completely. – Remove garments as soon as the programme has finished.
Silks handcare	**Max. load 1.0 kg***
Items	Silk garments which are suitable for drying in the tumble dryer, e.g. blouses and shirts.
Notes	– This programme reduces creasing. Items are not dried completely by this programme. – Remove garments as soon as the programme has finished.
Delicates	**Max. load 2.5 kg***
Normal, Hand iron	
Items	Delicate items with the ⊡ symbol on the care label made of synthetic fibres, easy care cotton or blended fabric, e.g. shirts, blouses, lingerie and evening wear with sequins and beading.
Note	Reducing the load will reduce creasing.
Express	**Max. load 4.0 kg**
Extra dry, Normal, Hand iron, Machine iron	
Items	Garments suitable for the Cottons programme.
Note	The programme duration is shorter.
Denim	**Max. load 3.0 kg**
Normal, Hand iron	
Items	Denim garments, e.g. jeans, jackets, skirts, shirts.

* Weight of dry laundry

Gentle smoothing	**Max. load 1.0 kg***
Normal, Hand iron	
Items	– Cotton and linen fabric. – Minimum iron items made of cotton, synthetic or mixed fibre, e.g. trousers, jackets, shirts.
Notes	– Suitable for dry and damp laundry. – Select *Hand iron* if the items are to be ironed after drying. – Smooths out creasing caused during the spin cycle in the washing machine. – Remove garments as soon as the programme has finished.
Warm air	**Max. load 8.0 kg**
Items	– Multi-layered fabric whose layers have different drying characteristics, e.g. jackets, pillows, sleeping bags and other voluminous items. – For drying individual items, e.g. bath towels, bathing costumes, tea-towels and small loads.
Note	Do not select the longest drying time to start with. Check the items as you are drying them to find the optimum time.
Tip	You can use the *Warm air* programme to help remove odours from clean cotton clothing (select a duration between 1/2 and 1 hour). Items must be suitable for drying in a tumble dryer. To improve the freshening up effect, dampen the garments a little beforehand and use a fragrance flacon (optional accessory). Odours will not be removed as effectively from any parts of the garments which are made of synthetic fibres.

* Weight of dry laundry

Changing the programme sequence

You cannot change to another programme once a programme has started (this prevents unintentional alterations).

If you try to change a programme, *-0-* lights up until the original programme is reset.

You will need to cancel the current programme before you can select a new one.

Cancelling a programme while it is running and selecting a new programme

- Press the *Start*/*Stop* button.

The items will be cooled down, depending on the temperature reached and how long they have been dried for. *0:00* will light up if you press the *Start*/*Stop* button again during this cooling down phase.

- Press the ⏻ button to switch the dryer off.
- Press the ⏻ button to switch the dryer on.
- Select and start a new programme straight away.

Adding or removing laundry after a programme has started

- Press the *Start*/*Stop* button.

The items will be cooled down, depending on the temperature reached and how long they have been dried for. *0:00* will light up if you press the *Start*/*Stop* button again during this cooling down phase.

⚠ Danger of burning!
Do not touch the back of the drum when adding or removing items. The drum and the items can be very hot.

- Add or remove items.
- Close the door.

To continue with the programme:

(select a drying level first of all, if necessary)

- Press the *Start*/*Stop* button.

Programme duration

Altering the programme sequence can cause the programme duration shown in the time display to be adjusted.


Emptying the condensed water container

The condensed water is collected in the condensed water container.


Empty the condensed water container after every drying programme.

The ⓘ indicator will light up if the maximum level of the condensed water container is reached.
To delete the ⓘ indicator: open and close the door with the dryer switched on.

⚠ To prevent damaging the door and the front of the condensed water container when pulling the container out of the dryer: always close the door completely.



- Pull out the condensed water container.
- Hold it at the front and towards the back and keep it in a horizontal position when carrying it.



- Empty the container.
- Replace the container in the dryer.

⚠ Condensed water should not be consumed. It could lead to health problems for people and animals.

Condensed water can be put to household use (e.g. used in a steam iron or humidifier). To ensure that any residual particles of fluff in the condensed water are removed before use, pass it through a fine sieve or paper filter first.

Fluff filters

This tumble dryer has 2 fluff filters in the door opening: the upper and lower fluff filters trap fluff produced during the drying process.


Removing visible fluff

Remove any fluff after every drying cycle.


Useful tip: You can also use a vacuum cleaner so that you can remove the fluff without touching it.

- Open the door.


⚠ You must remove the fragrance flacon (if present) beforehand (see "Fragrance flacon").



- Pull the upper fluff filter forwards to remove it.



- Remove the fluff (see arrows) . . .



- . . . from the surfaces of all the fluff filters.
- . . . from the perforated laundry deflector.
- Push the upper fluff filter back into position until it clicks.
- Close the door.


If there is a great deal of compacted fluff, carry out the following procedure.

Cleaning the fluff filters and air flow openings thoroughly


If the drying duration has become longer or the surface of the filters is visibly compacted with fluff, you should carry out the following cleaning procedure.

⚠ If using a fragrance flacon, make sure you remove it beforehand.


- Pull the upper fluff filter forwards to remove it.



- Turn the yellow dial on the lower fluff filter in the direction of the arrow (until you hear it click).



- Hold the dial and pull the fluff filter forwards to remove it.



- Use a vacuum cleaner with a long crevice nozzle attached to remove any visible fluff from the upper air flow openings.

Cleaning the fluff filters with water

- Flush the fluff filters through with warm running water.
- Shake the fluff filters thoroughly and then dry them carefully.

⚠ Ensure the filters are dry before replacing them. Wet filters could cause operational faults.


- Push the lower fluff filter in completely and lock it with the yellow dial.
- Push the upper fluff filter in completely.
- Close the door.

Plinth filter

Only clean the plinth filter when the ⊛ indicator lights up.


To delete the ⊛ indicator: open and close the door while the dryer is switched on.

Removing the plinth filter



- Press the round, indented area on the heat exchanger access panel to open it.


The panel will spring open.



- Pull the plinth filter out by the handle.

Removing the plinth filter will cause the right-hand guide pin in the dryer to come out. This pin ensures that the heat exchanger access panel can only be closed if the plinth filter is inserted the right way round.

Cleaning the plinth filter




- Pull the handle out of the plinth filter.
- Clean the filter thoroughly under running water.
- Squeeze the water out of the plinth filter thoroughly.

⚠ The plinth filter must not be replaced dripping wet as this can cause a fault.

- Use a damp cloth to remove any fluff from the handle.

Cleaning the plinth filter panel



- Use a damp cloth to remove any fluff. Make sure that you do not damage the rubber seal when doing this.
- Check whether the cooling fins are blocked with fluff (as follows).


Checking the heat exchanger unit

⚠ Danger of injury! Do not touch the cooling fins. You could cut yourself.

- Look to see if fluff has accumulated.


If there is visible soiling:

⚠ Clean using a vacuum cleaner with a dusting brush attached. Carefully pass the vacuum cleaner brush over the heat exchanger cooling fins without applying any pressure. Otherwise the cooling fins could be bent out of shape or become damaged.




- Carefully vacuum up any visible fluff or dirt.

Replacing the plinth filter



■ Fit the filter back on the handle. Make sure it is the correct way round.

To ensure that the filter is positioned correctly in the front of the heat exchanger unit:



■ First insert the handle with the plinth filter attached over the two guide pins.

– The word Miele on the handle must be the correct way up.

■ Push the plinth filter in completely.

The act of pushing in the plinth filter will also push in the right-hand guide pin.

■ Close the heat exchanger access panel.


⚠ The dryer can only be operated with the plinth filter fitted correctly and the heat exchanger access panel closed. The access panel must be closed correctly to ensure that water cannot leak from the condenser system and to ensure that the dryer functions efficiently.

Tumble dryer

⚠ Disconnect the machine from the mains electricity supply.

⚠ Do not use solvents, abrasive cleaners, glass cleaners or all-purpose cleaners.
These could damage plastic surfaces and other parts.

- Clean the tumble dryer with a slightly damp cloth and a mild non-abrasive cleaning agent or a solution of washing-up liquid and water.



- Clean the seal around the inside of the door with a damp cloth.
- Dry all parts with a soft cloth.
- The drum and other stainless steel parts can be cleaned with a suitable proprietary stainless steel cleaner following the manufacturer's instructions. This, however, is not absolutely necessary.


Fragrance flacon

Using a fragrance flacon (optional accessory) will add a pleasant fragrance to your laundry.

⚠ Before using a fragrance flacon, please read "Warning and safety instructions - Using a fragrance flacon (optional accessory)".

Inserting a fragrance flacon


Only hold the fragrance flacon as illustrated. Do not hold it at an angle or tip it as the fragrance will run out of the flacon.




- Hold the flacon securely to prevent opening it by mistake.
- Pull off the protective seal.
- Open the door of the tumble dryer.

The fragrance flacon is inserted in the upper fluff filter in the opening on the right-hand side beside the grip.


If you are not using a fragrance flacon: the cover must always remain closed (push the cover down completely with the tab).




- Open the cover using the tab until the tab is at the top right-hand side as shown.




- Insert the flacon in the opening as far as it will go.



Markers ① and ② must line up with one another.



■ Turn the outer ring Ⓡ clockwise a little.




– You will feel a slight resistance and hear a soft click.

Marker ② must be in position ⓪: this is the position at which you can feel a resistance.

Before drying

You can select the intensity of the fragrance.




■ Turn the outer ring clockwise: the further you open the flacon, the more intense the fragrance.

Fragrance flacon

Damp laundry and longer drying durations with sufficient heat transfer are needed for the fragrance to be released into the laundry effectively. The fragrance will also be noticeable in the room air during the process.

After drying

To avoid the fragrance escaping needlessly:




■ Turn the outer ring anti-clockwise until marker ② is in position ⓪.

– You will feel a slight resistance.


If you want to dry laundry without adding fragrance occasionally: remove the fragrance flacon and store it in its original packaging until you want to use it again. See the following section.

Replacing the fragrance flacon

When the fragrance is no longer sufficiently intense:




■ Turn the outer ring anti-clockwise until markers ① and ② line up.




■ Replace the fragrance flacon with a new one.

Fragrance flacons are available to order from Miele or online at www.miele-shop.com (depending on country).



⚠ Never lay the fragrance flacon down on any surface as the fragrance will run out.

Only store the fragrance flacon in its original packaging



– When storing the fragrance flacon in its original packaging whilst you are not using it, e.g. whilst cleaning the tumble dryer: to prevent the fragrance running out, do not store the packaging upright on its edge or upside down.

– Store in a cool, dry place.

– Store away from direct sunlight.

– When purchasing new fragrance flacons: only remove the protective seal just before use.

Cleaning the fluff filters

The intensity of the fragrance will be diminished if the fluff filters and the plinth filter are not cleaned.

⚠ The fragrance filter must be removed before cleaning the fluff filter.

⚠ To prevent any fragrance running out of the flacon:
when not in use, the fragrance flacon must only be stored in its original packaging as illustrated.

■ Clean the fluff filters and the plinth filter (see "Cleaning and care"). Afterwards, refit the fragrance flacon.

Problem solving guide

With the help of the following notes minor faults in the performance of the appliance, some of which may result from incorrect operation, can be put right without contacting Miele.

Please note that a call-out charge will be applied to service visits where the problem could have been rectified as described in these operating instructions.

⚠ Repair work to electrical appliances should only be carried out by an authorised Miele service technician. Repairs and other work by unqualified persons could be dangerous. Miele cannot be held liable for unauthorised work.

Check indicators and fault messages

Problem	Possible cause and remedy
The programme is cancelled, *0:00* lights up	This is not a fault. In some programmes, if the drum has been underloaded or is empty, the programme will be cancelled. This can also happen if the items are already dry. ■ Open and close the door to resume drying. ■ Use the *Warm air* programme (timed drying) to dry individual items.
--- flashes/lights up after the tumble dryer is switched on and a programme cannot be selected	Access via a code has been activated. ■ See "Programmable functions - *P07* Code".
and *FXX* (e.g. *F36*) light up after a programme is cancelled	There is no obvious cause. ■ Switch the dryer off and then on again. ■ Start a programme. If the programme is cancelled again and an error message appears, there is a fault. Contact Miele.

Problem	Possible cause and remedy
lights up at the end of a programme	There is a build-up of fluff in the airways. ■ Clean the fluff filters. ■ Clean the plinth filter. See "Cleaning and care". To switch off : ■ Open and close the door while the dryer is switched on.
and 066 light up after a programme is cancelled	An excessive amount of fluff has built up. ■ Clean the fluff filters. ■ Clean the plinth filter. Clean the airways: ■ Clean the area underneath the plinth filter. ■ Clean the heat exchanger. To switch off : ■ Switch the dryer off and back on again.
lights up after a programme is cancelled	The condensed water container is full or there is a kink in the drain hose. ■ Empty out the condensed water container. ■ Check the drain hose. To switch off : ■ Open and close the door while the dryer is switched on.
-0- lights up	The programme selector has been moved. ■ Select the original programme. The time remaining will appear in the display again.
Bars flash in the display at the end of a programme: [_]...[_]...[_]...	The programme has finished but the laundry has not yet cooled down. ■ Either remove the laundry and spread it out to cool down or leave it in the tumble dryer to cool down during the cooling phase.

Problem solving guide

Unsatisfactory drying results

Problem	Possible cause and remedy
The laundry is not sufficiently dry	The load consisted of different types of fabric. ■ Finish drying using the *Warm air* timed drying programme. ■ Select a more suitable programme next time. Tip: You can alter the drying levels for some programmes (see "Programmable functions").
Laundry or feather filled pillows smell after drying	The laundry was washed with insufficient detergent. Feathers are a natural product and this is quite normal. ■ Laundry: use sufficient detergent next time. ■ Pillows: take out of the tumble dryer and aerate. ■ Use a fragrance flacon (available as an optional accessory) for your favourite fragrance.
Items made of synthetic fibres are charged with static electricity after drying	Synthetic fibres tend to attract static charge. ■ Static charge can be reduced by adding a fabric softener to the final rinse in the washing programme.
There is a build-up of fluff	Fluff is principally the result of friction when garments are being worn and to some extent when they are being washed. Machine drying hardly causes any fluff to form. Fluff is collected by the fluff filters and the plinth filter and can be removed easily. ■ See "Cleaning and care".

Other problems

Problem	Possible cause and remedy
The drying process goes on too long or even switches off*	The room in which the tumble dryer is located is too warm. ■ Ventilate the room thoroughly.
	Detergent residues, hair and fine fluff can clog the filters. ■ Clean the fluff filters and the plinth filter. ■ Remove any visible fluff: . . . bottom left, from behind the panel in the heat exchanger cavity (see "Cleaning and care"); . . . from the cooling fins behind the grille bottom right (see the end of this section).
	The cool air intake (bottom right grille) is blocked. ■ Move any objects, such as a laundry basket, away from the dryer.
	The fluff filters and the plinth filter were wet when replaced. ■ The fluff filters and the plinth filter must be dry.
	The laundry is too damp. ■ Spin using a higher spin speed in the washing machine.
	The tumble dryer has been overloaded. ■ Do not exceed the maximum load for the programme selected.
	Metallic components, e.g. zippers have prevented the dryer from registering the correct moisture level. ■ Open the zippers next time. ■ If the problem recurs, dry these items using the *Warm air* timed drying programme.
	*** Before starting another programme:** ■ Switch the dryer off and then on again.
There are humming noises	The compressor is operating. These noises are quite normal and do not indicate a fault.

Problem solving guide


Problem	Possible cause and remedy
A programme cannot be started	There is no obvious cause. ■ Connect the tumble dryer to the mains electricity supply. ■ Turn on the tumble dryer. ■ Close the door. ■ Check whether the mains fuse has tripped.
	Has there been a power cut? When power is restored, any previously running programme will restart automatically.
The display is dark and the *Start*/*Stop* button is flashing slowly	The dryer is in standby. This is a normal function and does not indicate a fault. ■ See "Programmable functions - *P11* Standby".
	The drum will turn at intervals in the anti-crease phase.
The dryer is switched off at the end of the programme	The dryer switched off automatically. This is quite normal and does not indicate a fault. ■ See "Programmable functions - *P12* Automatic switch-off".
The interior drum lighting does not come on	The drum lighting will switch off automatically ... ... when the door is closed. ... after a few minutes when the door is open (to save energy). If the dryer is switched on, the drum lighting will come on when the door is opened.

Bottom right grille

⚠ In general, the cooling fins behind the grille on the bottom right do not need cleaning. They should only be cleaned if the drying process is taking an exceptionally long time due to a very high level of dust or fluff in the room in which the dryer is located.

- First open the plinth filter panel on the left from underneath.


To remove the grille, the catch behind it needs to be released using a spoon handle.



- Insert a spoon handle behind the grille in the middle.
- Press the spoon handle against the catch and lever the grille open.
- Remove the grille.

⚠ Danger of injury! Do not touch the cooling fins. You could cut yourself.

⚠ Use a vacuum cleaner with a dusting brush attached to clean the cooling fins. Only pass the vacuum cleaner brush over them lightly, without applying any pressure.
Take care not to bend the cooling fins out of shape or to damage them.




- Carefully vacuum up any visible fluff or dirt.
- Re-insert the 3 hooks on the grille into the appropriate holes in the front of the dryer.
- Press the grille firmly back into position by pressing it in at the middle on the left.

Repairs

In the event of any faults which you cannot remedy yourself, please contact Miele. Please note, however, that a call-out charge will be applied to service visits where the problem could have been rectified as described in these operating instructions.

The contact details for Miele are given at the back of these instructions.

When contacting Miele, please quote the model and serial numbers, both of which are located on the data plate (visible when the door is open).



Optional accessories

Optional accessories for this tumble dryer are available from Miele (see contact details at the back of these instructions).



You also can order these and many other useful products via the internet (depending on country).

Drying basket

The drying basket is suspended in the drum and does not rotate with the drum. This enables items which must not be subjected to mechanical action to be dried or aired.

Fragrance flacon


A fragrance flacon can be used in your tumble dryer to add a pleasant fragrance to your laundry.

Warranty

The manufacturer's warranty for this appliance is 2 years.

See the warranty card supplied with the tumble dryer for further details.

Front view



① Mains connection cable

② Control panel

③ Condensed water container
– empty after every drying cycle

④ Door
– do not open during drying


⑤ Heat exchanger access panel
– do not open during drying

⑥ Four height adjustable screw feet

⑦ Cool air intake grille
– do not obstruct with a laundry basket or other objects

⑧ Hose for external drainage of condensed water

Rear view



① Protruding lid for holding when moving the tumble dryer (see arrows)

② Accessories for external drainage of condensed water: hose clip, adapter and hose holder

③ Hose for external drainage of condensed water

④ Mains connection cable

Transporting the dryer


To manoeuvre the dryer out of its packing case to its installation site, hold it by


– the front feet

– and the protruding lid at the back of the appliance.

⚠ Only transport the dryer as shown in the following illustrations.

⚠ If transporting the dryer at an angle, only tip towards the left side.






⚠ If the tumble dryer has not been transported as described, then it must be left to stand for at least 1 hour before it is connected to the electricity supply.
Otherwise the heat pump can be damaged.


Installation

Levelling the dryer

The appliance must not be installed behind a lockable door, a sliding door or a door with a hinge on the opposite side to that of the tumble dryer, in such a way that a full opening of the tumble dryer door is restricted.
Make sure the dryer door can be opened without hindrance after installation.



The appliance must stand perfectly level to ensure safe and proper operation.



The screw feet can be adjusted to compensate for any unevenness in the floor.

Ventilation

⚠ The cool air intake at the front of the dryer must not be blocked or covered. This would hinder a sufficient intake of cool air for the heat exchanger.

⚠ Do not block the gap between the bottom of the tumble dryer and the floor with plinth facings, deep pile carpet etc. This would hinder a sufficient flow of air to the tumble dryer.
Adequate ventilation has to be provided to avoid the back flow of gases into the room from appliances burning other fuels, including open fires.

Air which is taken in to cool the heat exchanger is then blown back out of the dryer and warms up the air in the room. It is therefore very important to ensure adequate ventilation, e.g. by opening a window. Otherwise drying durations may be longer (increased energy requirement).

Before moving the tumble dryer again (e.g. when moving houses)

After each use a small quantity of condensed water will collect in the area of the pump. This water can run out if the tumble dryer is tipped up when it is being moved. Recommendation: Run the *Warm air* programme for approximately 1 minute before moving the tumble dryer. Any remaining condensed water will then be fed into the condensed water container, which can then be emptied, or out through the drain hose.

Additional installation requirements

⚠ The dryer should not be installed next to a refrigeration appliance. The warm air expelled from the rear of the dryer would increase the temperature around the refrigeration appliance's heat exchanger causing the compressor to run continuously. If it is not possible to install the dryer anywhere else, then the refrigeration appliance must be sealed off from the dryer.
It is very important to avoid a build-up of heat. The warm air which is expelled from the dryer must be able to dissipate. Warm air which cannot dissipate could cause a fault.

A build-up of heat can be avoided by:

– Adjusting the screw feet so that there is a gap of at least 20 mm between the floor and the bottom of the dryer.

– Creating a gap for the dryer in the kitchen furniture plinth facing.

– Creating ventilation gaps in the kitchen unit.

Suitable for pushing under a worktop

This tumble dryer is suitable for pushing under a worktop.

– The appliance lid must not be removed.

– The electrical socket must be located in an accessible position near the appliance.

– Drying durations may increase slightly.

Optional accessories

– Washer-dryer stack

The tumble dryer can also be combined with a Miele washing machine in a washer-dryer stack. The appropriate Miele washer-dryer stacking kit is required.

Externally draining condensed water

Notes

When drying is in progress, condensed water is pumped into the condensed water container through the drain hose which is located at the back of the dryer.

The condensed water can also be drained away via the drain hose so that the condensed water container does not have to be emptied.

Drain hose length: 1.60 m
Maximum delivery head: 1.50 m
Maximum drain hose length: 4.00 m

The following optional accessories are available:

– an extension hose,

– a non-return valve kit for connection to an external water outlet. The kit includes an extension hose.

Installation conditions requiring a non-return valve

⚠ There is a risk of backflow into the dryer if a non-return valve is not fitted.
Backflow could damage the dryer and also the room in which it is located.
Certain installation conditions, such as those described below, require the fitting of a non-return valve.

Maximum delivery head with non-return valve fitted: 1.00 m

Installation conditions requiring the fitting of a non-return valve:

– Drainage into a sink or floor gully where the end of the hose is immersed in water.

– Connection to a sink drain outlet.


– Connection to a drainage system already in use by another appliance, e.g. a dishwasher or washing machine.

⚠ The non-return valve has to be fitted with the arrow pointing in the direction of flow.
Otherwise water will not drain out of the appliance.


Arranging the drain hose

⚠ Do not pull on the drain hose and do not stretch it or allow it to become kinked.
This could damage the hose.

There will be a small amount of residual water left in the drain hose. Have a container ready to collect this.



- Pull the drain hose off its connection.
- Unwind the hose and pull it carefully out of the holders.
- Allow any residual water to run into the container.



- Guide the hose to the right or left side of the dryer, as required.


– If you are guiding it to the right, you can fit the hose into the groove.

– Leave the hose in the lower holder to prevent it from being kinked inadvertently.

Examples

– Drainage into a sink or floor gully

Use the hose holder to prevent the drain hose from becoming kinked.




- Press the small catches on the left and right of the hose holder with your thumbs (black arrows) and ...
- ... pull the hose holder forwards to remove it (white arrows).*

⚠ If you want to drain the water off into a sink or basin, you will need to secure the hose carefully, e.g. by tying it to a tap, to make sure it cannot slip during use (see the drawing under "Installation and connection - Front view").
Overflowing water can cause damage.


- The non-return valve can be fitted in the end of the hose.

* You can refit the hose holder at a later stage if you decide that you no longer want to drain the condensed water externally.

Direct connection to a sink drain outlet



- Remove the following from the back of the dryer at the top: Adapter **1** and hose clip **3** behind it.
- Connect the drain hose as described below.



1. Adapter
2. Nut
3. Hose clip
4. End of the hose (secured with the hose holder)
5. Non-return valve
6. Tumble dryer drain hose

- Fit the adapter **1** to the sink drain outlet using the nut **2**.
  The nut is usually fitted with a washer which must be removed.
- Attach the end of the hose **4** to the adapter **1**.
- Use the hose holder.
- Use a screwdriver to tighten the hose clip **3** up close to the nut.
- Fit the non-return valve **5** to the tumble dryer drain hose **6**.

The non-return valve **5** has to be fitted so that the arrow points in the direction of flow (i.e. towards the sink).

- Secure the non-return valve using hose clips.

Electrical connection

This tumble dryer is supplied with a mains cable with moulded plug.

The accessibility of the plug must be always ensured in order to separate the tumble dryer from the mains.

Connection of this appliance should comply with national and local safety regulations.

Do not connect the appliance via an extension lead. Extension leads do not guarantee the required safety of the appliance (e.g. danger of overheating).

The appliance should be connected up only by a qualified electrician in accordance with national and local safety regulations. For extra safety, it is advisable to install a residual current device (RCD) with a trip current of 30 mA.

The voltage, rated load and plug rating are given on the data plate. Please ensure that these match the household mains supply.

Important

The wires in the mains lead are coloured in accordance with the following code:
Green/yellow = earth
Blue = neutral
Brown = live
As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows: The wire which is coloured green and yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol or coloured green or green and yellow. The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter A or coloured red.

WARNING
THIS APPLIANCE MUST BE EARTHED

	Load[1]	Final spin speed in a domestic washing machine	Residual moisture	Energy	Duration
	kg	rpm	%	kWh	min.
Cottons	8.0	1000	60	2.14	156
	4.0	1000	60	1.28	94
Cottons Normal	8.0	1200	53	1.90	141
	8.0	1400	50	1.80	134
	8.0	1600	44	1.60	119
Cottons Normal + Gentle tumble	8.0	1000	60	2.19	163
Cottons Hand iron	8.0	1000	60	1.52	115
	8.0	1200	53	1.35	101
	8.0	1400	50	1.25	94
	8.0	1600	44	1.05	80
Minimum iron Normal + Gentle tumble	4.0	1200	40	.69	55
	4.0	1200	40	.80	60
Minimum iron Hand iron	4.0	1200	40	.60	48
Denim Normal	3.0	900	60	1.42	106
Express Normal	4.0	1000	60	1.20	88
[1] Weight of dry laundry					
All data was calculated using EN 61121 unless otherwise stated.					
Power consumption when switched off: 0.15 W Power consumption when not switched off: 1.50 W					

Consumption data can vary from the nominal values given above depending on the size of the load, types of textiles, residual moisture levels after spinning, fluctuations in the electricity supply and any options selected.

Using the Cottons Extra dry programme is recommended for a mixed cotton load and is the programme used in energy consumption tests to AS/NZS 2442 (Refer to www.energyrating.gov.au website for consumption data).

Technical data

Height	850 mm
Width	596 mm
Depth	636 mm
Depth with door open	1054 mm
Height for building under	850 mm (+5/-5 mm)
Width for building under	600 mm
Depth for building under	600 mm
Suitable for pushing under a worktop	Yes
Suitable for stacking	Yes
Weight	Approx. 61 kg
Drum volume	120 l
Maximum capacity	8.0 kg (weight of dry laundry)
Capacity of condensed water container	4.8 l
Drain hose length	1.60 m
Maximum delivery head	1.50 m
Maximum drain hose length	4.00 m
Length of connection cable	2.00 m
Voltage	See data plate
Rated load	See data plate
Fuse rating	See data plate
Test certificates awarded	See data plate
Energy consumption	See "Consumption data"
LEDs	Class 1

Programmable functions for changing standard settings

Settings can be used to alter the dryer's electronics to suit different requirements. They can be altered at any time.

The tumble dryer's programmable functions are available for use but are not absolutely necessary for a satisfactory drying result.

Programming

You can use the programmable functions to alter the dryer's electronics to suit your requirements.

Please read the following pages which describe the various individual programmable functions so that you are aware of the effect selecting the different options will have on your dryer.

Programming is carried out in 8 steps (❶, ❷, ❸ ... ❽) using buttons and sensors.

I) Accessing a programmable function

Before you begin, ensure the following:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start*/*Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the tumble dryer on.

Wait until the indicator light for the *Start*/*Stop* button lights up constantly . . .

❸ . . . and then release the *Start*/*Stop* button.

II) Selecting the programmable function

The number of the programmable function will appear in the display as *P* and a number:
e.g. *P01*.

❹ Touch the ◇ sensor to select the other programmable functions one by one:

Programmable function	
P01	*Cottons* programme - drier or damper
P02	*Minimum iron* programme - drier or damper
P04	Extended cool down
P05	Buzzer volume
P06	Keypad tones
P07	PIN Code
P08	Conductivity
P09	Additional drying levels
P11	Standby
P12	Automatic switch-off
P13	Memory
P14	Anti-crease

❺ Confirm your selection of the programmable function by pressing the *Start*/*Stop* button.

III) Selecting a different option

The options allow you to alter the features of the particular programmable function.

The option will appear in the time display as - and a number: e.g. -00 or -01 or -02 etc.

❻ Touch the ◇ sensor to switch to the next option:

Programmable function	Available options							
	-00	-01	-02	-03	-04	-05	-06	-07
P01		X	X	X	O	X	X	X
P02		X	X	X	O	X	X	X
P04	O	X	X	X	X	to		-09
P05		O	X					
P06	O	X						
P07	O	X						
P08		O	X					
P09	O	X						
P11	X	X	O					
P12		X	O	X				
P13	O	X						
P14	X	X	O					

X = Can be selected
O = Factory default setting

❼ Confirm your selection of the option selected by pressing the *Start*/*Stop* button.

The number of the programmable function: e.g. P01 will light up again.

IV) Exiting programming

❽ Switch the tumble dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

The following example may be helpful in illustrating the programming procedure.

Example

This example describes how to call up the "P06 Keypad tone" programmable function. When the keypad tone programmable function is switched on, a tone will sound every time a button is pressed when operating the dryer.

I) Accessing programming

Before you begin, ensure the following:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start*/*Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the tumble dryer on.

Wait until the indicator light for the *Start*/*Stop* button lights up constantly . . .

❸ . . . and then release the *Start*/*Stop* button.

P01 lights up.

II) Selecting the programmable function

❹ Touch the ◇ sensor repeatedly until P06 lights up.

❺ Confirm selection of P06 by pressing the *Start*/*Stop* button.

III) Selecting a different option

-00 will light up in the time display. These numbers mean that the keypad tone is switched off.

To switch on the keypad tone:

❻ Touch the ◇ sensor so that -01 lights up.

❼ Confirm selection of -01 by pressing the *Start*/*Stop* button.

P06 will light up again.

IV) Exiting programming

❽ Switch the tumble dryer off.

Checking the programming

■ Switch the tumble dryer on.

■ Press any button.

A tone will sound each time you press a button.

■ Switch the tumble dryer off.

Reverting to the previous programming

■ You can switch off the keypad tone at any time by repeating the steps described in this example.

Select the -00 option in step ❻.

P01 Cottons programme - drier or damper

or

P02 Minimum iron programme - drier or damper

The electronics are designed to dry as effectively as possible. However, if you require the laundry to be drier or damper, you can alter all the drying levels for one of these programmes at the same time.

Options

-01 very damp
-02 damp
-03 a little damp
-04 **factory default**
-05 a little dry
-06 dry
-07 very dry

Exception:
The *Cottons* ⟨ programme will remain unchanged.

P04 Extended cool down

The automatic cooling down phase which takes place before the end of a programme can be extended for all programmes with selectable drying levels. This makes the garments easier to handle.

Options

-00 **factory default**
-01 cool down time 2 min. longer
-02 cool down time 4 min. longer
-03 cool down time 6 min. longer
-04 cool down time 8 min. longer
-05 cool down time 10 min. longer
-06 cool down time 12 min. longer
-07 cool down time 14 min. longer
-08 cool down time 16 min. longer
-09 cool down time 18 min. longer

P05 Buzzer volume

The buzzer can be set so that it is louder.

-01 **Factory default**
-02 Buzzer louder

P06 Keypad tones

When this function is activated, a tone will sound each time a button is pressed.

The volume of the keypad tone will depend on the setting selected for "P05 Buzzer volume".

Options

-00 **Factory default: off**
-01 Keypad tone on

P07 PIN Code

The code prevents your machine being used without your knowledge.

When the code has been activated, you have to enter a code after switching the dryer on. Otherwise the dryer cannot be operated.

Options

-00 **Factory default: off**
-01 Code on

If option -01 has been selected, after switching on you will have to enter the code before you can operate the dryer.

Using the dryer when the code is activated

After the dryer is switched on, --- will flash in the time display.

The code is 250 and cannot be altered.

- Touch the ◈ sensor until a 2-- flashes in the first position.
- Confirm this by pressing the *Start/ Stop* button.
- Enter the two other numbers in the same way.

The dryer is ready for use after 250 has been entered and confirmed.

P08 Conductivity

⚠ This setting should only be altered if the water is so soft that it is likely to cause the electronics which sense residual moisture in the laundry to give false readings.

Important

This option should not be activated if, despite the water being extremely soft (as would be the case if a water softener were used), its conductivity is greater than 150 µS/cm.

⚠ Only activate this programmable function for the conditions described above.
Otherwise drying results can be unsatisfactory.

Options

-01 **Factory default: off**
-02 Low conductivity

P09 Additional drying levels

You can activate additional drying levels for many of the programmes:
Normal+ (drier than the Normal drying level);
Slightly dry (damper than Normal drying level);
Hand iron ♨♨ (damper than the Hand iron drying level).

This programmable function is only available for programmes with a selectable drying level.

Options

-00 **Factory default**
-01 Drying level stages added

Once this programmable function has been activated, you will have the option of selecting the additional drying levels when you select a programme.

- Select a programme with selectable drying levels.
- Touch the ∨ sensor until two drying levels light up:

Drying level	The following light up in the display
Extra dry	*Extra dry*
Normal+	*Extra dry* *Normal*
Normal	*Normal*
Slightly dry	*Normal* *Hand iron*
Hand iron	*Hand iron*
Hand iron ♨♨	*Hand iron* *Machine iron*
Machine iron	*Machine iron*

P11 Standby

To save energy, the display and buttons will go out after 10 minutes and only the *Start*/*Stop* button will flash slowly. You can alter this setting.

However, standby mode will not occur in the event of a fault.

Options

-02 **Factory default: Standby is switched on**

The display and buttons will go out after 10 minutes . .
. . . if no selection is made after switching the dryer on.
. . . after a programme has started.
However, the display and buttons will remain lit up for 10 minutes after a Delay start time has elapsed, after the end of the programme or at the end of the anti-crease phase. The buzzer, if selected, will sound for 10 minutes after the end of the programme.

-01 Not in current programme

As described under *-02*.
However, the display and buttons will remain lit up during the programme.

-00 Off

The display and buttons will remain lit up while the dryer is switched on.

To switch the display and buttons back on again:

– Turn the programme selector or press a button. Neither will have any effect if a programme is running.

– Open the door while the dryer is switched on.

P12 Automatic switch-off

To save energy, the dryer will switch off automatically after 15 minutes. You can lengthen or shorten the time.

However, there is no automatic switch-off in the event of a fault.

The dryer will switch off automatically after 15 minutes:

– if no further selection is made after switching the dryer on.

– at the end of the anti-crease phase.

– after a programme without an anti-crease phase has finished.

Options

-01 Switch-off after 10 minutes
-02 **Factory default: Switch-off after 15 minutes**
-03 Switch-off after 20 minutes

P13 Memory

The electronics will store in memory a drying level or options for a selected programme. The duration selected for a timed drying programme will also be stored in memory. These settings will then appear the next time the programme is chosen.

Options

-00 **Factory default: Memory off**
-01 Memory on

Exception:
The *Cottons* programme will remain unchanged.

P14 Anti-crease

If you have pressed the *Anti-crease* button: the drum will continue to rotate in a special anti-crease rhythm for a maximum of 2 hours after the end of the drying process. This helps prevent creasing if laundry is not going to be removed immediately. You can reduce the duration of the anti-crease phase.

Options

-01 Anti-crease - 1 hour
-02 **Factory default: Anti-crease - 2 hours**

Miele Australia Pty. Ltd.
ACN 005 635 398
ABN 96 005 635 398

Miele Center and Head Office Melbourne:
1 Gilbert Park Drive
Knoxfield, VIC 3180

Miele Center and Office Melbourne:
206-210 Coventry Street
South Melbourne, VIC 3205

Miele Center and Office Sydney:
3 Skyline Place
Frenchs Forest, NSW 2086

Miele Center and Office Brisbane:
39 Harvey Street North
Eagle Farm, QLD 4009

Miele Center and Office Adelaide:
83-85 Sir Donald Bradman Drive
Hilton, SA 5033

Miele Center and Office Perth:
205-207 Stirling Highway
Claremont, WA 6010

1300 4 MIELE (1300 464 353)

www.miele.com.au



Miele New Zealand Limited
IRD 98 463 631

Head Office:
Level 2, 10 College Hill
Freemans Bay, Auckland 1011

Miele Center Auckland:
8 College Hill
Freemans Bay, Auckland 1011

Telephone:
0800 4 MIELE (0800 464 353)

www.miele.co.nz

Miele Global Headquarters Germany
Miele & Cie. KG
Carl-Miele-Straße 29
33332 Gütersloh
Federal Republic of Germany

Miele

TKB 350 WP

CE

en-AU, NZ

M.-Nr. 10 205 050 / 01